


# TROUBLESHOOTING Hooking-Up and Linking





# There are two general sections:

- Section A. Problems <u>Hooking-Up in AP mode</u>; meaning, not being able to make the basic link to your tool from your device; or not able to get back to the basic AP link.
- **Section B**. Problems <u>Hooking-Up to your</u>
  <u>Network</u>; in this case, you are able to link to
  your tool in AP mode, but not able to get the tool
  to go onto your network.
  - \* To diagnose Network problems (B), bring up your Handibot in AP mode and jump to Section B of this document, page 10

[Section A (AP)]


3


<u>Section A</u>. Problems <u>Hooking-Up in AP</u> <u>mode</u>: not being able to make the basic link to your tool from your device; or not able to get back to the basic AP link.


### **Preliminary Checks**

- Re-Power Your Tool: Turning your Handibot OFF then ON will give all process a chance to re-start and clear;
   Wait 2 min to allow everything to shake out ...
- **Device Wireless(Wi-Fi):** Make sure your device's wireless system is turned on and enabled.

Ok, let's go to work on fixing that AP mode link ...







[Section A (AP) -- cont]

9

### There's one last thing we can try here:

- Attempting to get onto the internet from the Updater itself and the trying again to start the update process.
- Use Network function on the left-side menu to get on the internet and attempt the update.
- It this does not work, then you will need to reflash the full image on your Handibot.

(go to: Re-Flash FabMo Document)



<u>Section B</u>. Problems <u>Hooking-Up to your</u> <u>Network</u>. You are able to link to your tool in Anchor Point (AP) mode, but not able to link your tool to your Network.

## **Preliminary Checks**

- Make sure you have the correct passcode for your network; Handibot/FabMo will not currently link to a network that requires a user name.
- Get Handibot closer to your wireless router: Your Handibot needs good signal strength to link and maintain a network connection.

Ok, let's get to work getting onto that network ...

